



DuraCoat® Shake ‘N Spray Finishing Kit Instructions

- 1) Prep your metal, plastic or wood parts by spraying the TruStrip™ Cleaner/Degreaser causing the oil and grime to run off. Then scuff with the enclosed pad keeping the pad saturated with TruStrip.
- 2) Shake the DuraCoat® bottle for three minutes then pour the entire contents into the glass jar. Add the entire contents of the enclosed DuraCoat® Hardener. Screw the white cap onto the jar and shake for one minute. Remove the cap and screw on the Preval sprayer.
- 3) Spray your parts in thin, even passes. Allow the part to dry for 5 minutes in between coats. Apply approximately three coats.
- 4) Hang your parts to dry. Allow to dry overnight before assembly. Only expose the parts to light use during the 3-4 week cure time. Once fully cured, your parts will not scratch or chip and will be resistant to all solvents and cleaners.